



UNIVERSITY OF CAMBRIDGE INTERNATIONAL EXAMINATIONS International General Certificate of Secondary Education

CANDIDATE NAME								
CENTRE NUMBER						CANDIDATE NUMBER		
CHEMISTRY							062	20/52
Paper 5 Practic	al Test						May/June	2013
							1 hour 15 min	utes
Candidates ans	wer on t	he Ques	tion Pa	aper.				
Additional Mate	rials:	As liste	ed in th	e Co	onfidential Instruction	S		

READ THESE INSTRUCTIONS FIRST

Write your Centre number, candidate number and name on all the work you hand in.

Write in dark blue or black pen.

You may use a pencil for any diagrams, graphs or rough working.

Do not use staples, paper clips, highlighters, glue or correction fluid.

DO NOT WRITE IN ANY BARCODES.

Answer all questions.

Electronic calculators may be used.

You may lose marks if you do not show your working or if you do not use appropriate units.

Practical notes are provided on page 8.

At the end of the examination, fasten all your work securely together.

The number of marks is given in brackets [] at the end of each question or part question.

For Examiner's Use			
Total			

This document consists of 6 printed pages and 2 blank pages.



1 You are going to investigate the reaction between solution **A**, aqueous potassium manganate(VII), and two different solutions, **B** and **C**, of an acidic solution of a sodium salt.

For Examiner's Use

Read all the instructions below carefully before starting the experiments.

Instructions

You are going to carry out two experiments.

(a) Experiment 1

Fill the burette with the solution **A** of potassium manganate(VII) to the 0.0 cm³ mark.

Using a measuring cylinder, pour 25 cm³ of solution **B** into the conical flask. Place the flask on a tripod and gauze and heat the mixture in the flask to about 80 °C.

Remove the flask from the tripod and place it on the white tile under the burette. Slowly add $1\,\mathrm{cm^3}$ of the solution **A** to the flask, with shaking. Continue to add solution **A** to the flask until the mixture just turns permanently pink. Record the burette reading in the table and complete the table.

Pour away the contents of the conical flask and rinse the flask with distilled water.

final burette reading/cm³	
initial burette reading/cm³	
difference/cm ³	

[3]

(b) Experiment 2

Refill the burette with the solution **A** of potassium manganate(VII).

Using a measuring cylinder, pour $25\,\mathrm{cm^3}$ of solution $\mathbf C$ into the conical flask. Heat the mixture in the flask to about $80\,^\circ\mathrm{C}$.

Remove the flask from the tripod and place it on the white tile under the burette. Slowly add $1\,\text{cm}^3$ of the solution **A** to the flask, with shaking. Continue to add solution **A** to the flask until the mixture just turns permanently pink. Record the burette readings in the table and complete the table.

final burette reading/cm ³	
initial burette reading/cm³	
difference/cm ³	

[3]

(c)	(i)	Suggest why the mixture in the flask is heated before adding the potassium manganate(VII) solution.
		[1]
	(ii)	What colour change was observed when potassium manganate(VII) solution was added to the flask in Experiment 1?
		from to
((iii)	Why is an indicator not added to the flask?
		[1]
(d)	(i)	In which experiment was the greater volume of potassium manganate(VII) solution used?
		[1]
	(ii)	Compare the volumes of potassium manganate (VII) used in Experiments 1 and 2.
		[1]
((iii)	Suggest an explanation for the difference in volumes.
		[2]
(e)		xperiment 2 was repeated using $12.5\mathrm{cm^3}$ of solution \mathbf{C} , what volume of potassium nganate(VII) solution would be used? Explain your answer.
		[3]
(f)		edox reaction occurs when potassium manganate(VII) reacts with solutions ${\bf B}$ and ${\bf C}$. Idain the term redox reaction.
		[2]
(g)	Giv	e one advantage and one disadvantage of using a measuring cylinder for solution C .
	adv	antage
	disa	advantage[2]
		[Total: 24]

You are provided with a mixture of two solids, **R** and **S**.
Solid **R** is water-soluble and solid **S** is insoluble.
Carry out the following tests on the mixture, recording all of your observations in the table.
Conclusions must not be written in the table.

tests	observations
Add about 15 cm³ of distilled water to the mixture in a boiling tube. Shake the boiling tube for one minute. Filter the contents of the boiling tube, keeping the filtrate and residue for the following tests. Divide the filtrate into five test-tubes.	[1]
tests on the filtrate	
(a) Use pH indicator paper to measure the pH of the first portion of the filtrate.	[1]
 (b) (i) Add several drops of aqueous sodium hydroxide to the second portion of the solution and shake the test-tube. Now add a large excess of aqueous sodium hydroxide. (ii) Using the third portion of solution, repeat test (b)(i) using aqueous ammonia instead of aqueous sodium hydroxide. 	
(c) Add about 1 cm³ of dilute nitric acid to the fourth portion of the solution followed by aqueous silver nitrate.	[1]
(d) To the fifth portion of the solution add about 1 cm³ of dilute nitric acid followed by aqueous barium nitrate.	[2]

For
Examiner's
1100

tests	observations
tests on the residue	
Use a spatula to transfer some of the residue into the bottom of a test-tube.	
(e) To the residue, add about 2 cm³ of dilute hydrochloric acid.	
Test the gas given off.	
	[3]
Now add a large excess of aqueous sodium hydroxide to the mixture.	[2]
(f) What conclusions can you draw about s	solid R ?
	[2]
(g) Name the gas given off in test (e).	
	[1]
(h) Identify solid S.	
	[2]
	[Total: 19]

[Total: 19]

BLANK PAGE

BLANK PAGE

NOTES FOR USE IN QUALITATIVE ANALYSIS

Test for anions

anion	test	test result
carbonate (CO ₃ ²⁻)	add dilute acid	effervescence, carbon dioxide produced
chloride (C <i>l</i> ⁻) [in solution]	acidify with dilute nitric acid, then add aqueous silver nitrate	white ppt.
iodide (I ⁻) [in solution]	acidify with dilute nitric acid, then add aqueous silver nitrate	yellow ppt.
nitrate (NO ₃ ⁻) [in solution]	add aqueous sodium hydroxide then aluminium foil; warm carefully	ammonia produced
sulfate (SO ₄ ²⁻) [in solution]	acidify with dilute nitric acid, then aqueous barium nitrate	white ppt.

Test for aqueous cations

cation	effect of aqueous sodium hydroxide	effect of aqueous ammonia
aluminium (Al³+)	white ppt., soluble in excess giving a colourless solution	white ppt., insoluble in excess
ammonium (NH ₄ ⁺)	ammonia produced on warming	_
calcium (Ca ²⁺)	white ppt., insoluble in excess	no ppt., or very slight white ppt.
copper (Cu ²⁺)	light blue ppt., insoluble in excess	light blue ppt., soluble in excess giving a dark blue solution
iron(II) (Fe ²⁺)	green ppt., insoluble in excess	green ppt., insoluble in excess
iron(III) (Fe ³⁺)	red-brown ppt., insoluble in excess	red-brown ppt., insoluble in excess
zinc (Zn ²⁺)	white ppt., soluble in excess giving a colourless solution	white ppt., soluble in excess giving a colourless solution

Test for gases

gas	test and test results	
ammonia (NH ₃)	turns damp red litmus paper blue	
carbon dioxide (CO ₂)	turns limewater milky	
chlorine (Cl ₂)	bleaches damp litmus paper	
hydrogen (H ₂)	'pops' with a lighted splint	
oxygen (O ₂)	relights a glowing splint	

Permission to reproduce items where third-party owned material protected by copyright is included has been sought and cleared where possible. Every reasonable effort has been made by the publisher (UCLES) to trace copyright holders, but if any items requiring clearance have unwittingly been included the publisher will be pleased to make amends at the earliest possible opportunity.

University of Cambridge International Examinations is part of the Cambridge Assessment Group. Cambridge Assessment is the brand name of University of Cambridge Local Examinations Syndicate (UCLES), which is itself a department of the University of Cambridge.